

Installation Instructions For Loading Dock Door Nets With Floor Mounted Bollard

www.usnetting.com

1-800-331-2973



STEP 1
Clean Area



STEP 5
Clean Surface



STEP 2
Measure 3" from door rail. Be sure ballard is 1 1/2" covering door rail protection



STEP 6
Install bottom base and fasten with washers and nuts



STEP 3
Mark 5 Holes (marker enclosed)



STEP 7
Insert Top Bollard



STEP 4
Drill holes 3" deep (drill bit included)
-Note- Make sure holes are clean before insertion



STEP 8
Attach Eyebolt

INSTALLATION STEPS



1. Select a carbide drill bit with a diameter equal to the anchor diameter. Drill hole to any depth exceeding the desired embedment. See chart for minimum recommended embedment.
 2. Clean hole or continue drilling additional depth to accommodate drill flutes.
 3. Assemble washer and nut, leaving nut flush with end of anchor to protect threads. Drive anchor through material to be fastened until washer is flush to surface of material.
 4. Expand anchor by tightening nut 3-5 turns past the hand tight position, or to the specified torque requirement.
- NOTE:** Read **Caution** on back cover before installation.



STEP 9
Attach Net